


CIF - End cap

End cap for socket welding.



Reference	d	PN	H	E	g
CIF016	*16	16	20	23	7
CIF020	20	16	23	28	11
CIF025	25	16	27	33	19
CIF032	32	16	31	41	32
CIF040	40	16	36	50	47
CIF050	50	16	43	61	75
CIF063	63	16	51	76	135
CIF075	*75	16	58	90	215
CIF090	*90	16	68	109	400
CIF110	*110	16	81	130	630